PRIMECEDAR

Care and Finish

Before beginning any staining we suggest a light sanding of the product with an orbital sander and 110 grit sand paper to aid in stain penetration.

Stain:	If deck boards have not been prestained (see installation tips), apply a protective oil-based stain as soon as possible. Make sure the stain contains:
	 UV protection Water-repellent preservative Mildewcide
	A stain with some pigment will be more effective than a completely clear coating. Select a premium penetrating oil stain rather than paint. (Consider a product line that offers a stain for hardwoods for a maximum penetrating formula.) Always follow instructions on a manufacturer's label. Do not use a solid dark stains or paint.
Keep Clean:	Remove dirt on a regular basis with a commercial deck wash or a household recipe of 1 quart bleach, 3 quarts warm water, 2/3 cup TSP, 1/3 cup detergent*. NO AMMONIA. Sand lightly if wood fibers are raised.
Refinish:	Refinish a clean deck on the schedule recommended by the stain manufacturer. If a deck is built in the fall or winter and cannot be stained immediately due to temperatures, plan to clean and finish the deck as soon as possible in the spring.
	* A bleach formula is recommended when a mildew or algae is detected.

* A bleach formula is recommended when a mildew or algae is detected. Take care to cover and protect adjacent vegetation during use.



54 Governor Dukakis Drive PO Box 116 Orange, MA 01364

1-800-504-8044 www.pfpdist.com

PRIMECEDAR

Installation Tips

Storage:	Keep dry by placing blocks under lumber for ventilation. Do not store directly on the ground. Cover with tarp.
Protect:	For maximum performance, pre-stain deck boards and railing components on all sides prior to installation. Select a premium penetrating oil stain rather than paint. Consider a product line that offers a stain for hardwoods for a maximum penetrating formula. Seal all end cuts.
Site Preparation:	Clear rocks and debris from site. Grade site for proper drainage. Remove vegetation and lay down landscape paper or poly. Maintain sufficient air flow under deck.
Space:	Leave at least 1/8" gap between deck boards.
Predrill:	Predrill ends to avoid splitting.



54 Governor Dukakis Drive PO Box 116 Orange, MA 01364

1-800-504-8044 www.pfpdist.com